



★ Shift Action (Shift + )

- 1 FX 1 Dry/Wet
- 2 Deck A Filter
- 3 Deck A Filter On/Off
- 4 Deck A Absolute/Relative Mode
- 5 FX 2 Dry/Wet
- 6 Deck B Filter
- 7 Deck B Filter On/Off
- 8 Deck B Absolute/Relative Mode

### MIDI Page 1 (FX Unit 1)

- 17 Load Select Deck A  
Shift + Adv.Panel Sel A (Move)
- 18 Load Select Deck B  
Shift + Adv.Panel Sel B (Move)
- 19 Favorite Select Prev  
Shift + Adv.Panel Sel A (Cue)
- 20 Favorite Select Next  
Shift + Adv.Panel Sel B (Cue)
- 21 Track Select  
Shift + Tree Select  
Shift + Tree Expand/Collapse (Push)  
List Mode (Push)
- 22 Snap Mode On/Off



### MIDI Page 1 (FX Unit 1)

- |  |  |  |  |   |
|--|--|--|--|---|
| 9 Adv.FX 1 Dry/Wet<br>Adv.FX Efx On (Push)<br>Chain FX Dry/Wet | 10 Adv.FX 1 Parameter 1<br>Adv.FX Button 1 (Push)<br>Chain FX Amount 1<br>Shift + Chain FX Sel 1 | 11 Adv.FX 1 Parameter 2<br>Adv.FX Button 2 (Push)<br>Chain FX Amount 2<br>Shift + Chain FX Sel 2 | 12 Adv.FX 1 Parameter 3<br>Adv.FX Button 3 (Push)<br>Chain FX Amount 3<br>Shift + Chain FX Sel 3 | 14 Deck A FX 1 On/Off<br>Shift + FX Unit 1 Adv.Mode   |
|  |  |  | 13 Deck A Key On/Off   | 15 Deck A FX 2 On/Off<br>Shift + FX Unit 1 Chain.Mode |
|  |  |  |  | 16 Deck A Sync  |





★ Shift Action (Shift + )

- 1 FX 1 Dry/Wet
- 2 Deck A Filter
- 3 Deck A Filter On/Off
- 4 Deck A Absolute/Relative Mode
- 5 FX 2 Dry/Wet
- 6 Deck B Filter
- 7 Deck B Filter On/Off
- 8 Deck B Absolute/Relative Mode

### MIDI Page 2 (FX Unit 2)

- 17 Load Select Deck A  
Shift + Adv.Panel Sel A (Move)
- 18 Load Select Deck B  
Shift + Adv.Panel Sel B (Move)
- 19 Favorite Select Prev  
Shift + Adv.Panel Sel A (Cue)
- 20 Favorite Select Next  
Shift + Adv.Panel Sel B (Cue)
- 21 Track Select  
Shift + Tree Select  
Shift + Tree Expand/Collapse (Push)  
List Mode (Push)
- 22 Snap Mode On/Off



### MIDI Page 2 (FX Unit 2)

- |  |  |  |  |   |
|--|--|--|--|---|
| 9 Adv.FX 1 Dry/Wet<br>Adv.FX Efx On (Push)<br>Chain FX Dry/Wet | 10 Adv.FX 1 Parameter 1<br>Adv.FX Button 1 (Push)<br>Chain FX Amount 1<br>Shift + Chain FX Sel 1 | 11 Adv.FX 1 Parameter 2<br>Adv.FX Button 2 (Push)<br>Chain FX Amount 2<br>Shift + Chain FX Sel 2 | 12 Adv.FX 1 Parameter 3<br>Adv.FX Button 3 (Push)<br>Chain FX Amount 3<br>Shift + Chain FX Sel 3 | 14 Deck B FX 1 On/Off<br>Shift + FX Unit 1 Adv.Mode   |
|  |  |  | 13 Deck B Key On/Off   | 15 Deck A FX 2 On/Off<br>Shift + FX Unit 1 Chain.Mode |
|  |  |  |  | 16 Deck B Sync  |





★ Shift Action (Shift + )

- 1 FX 1 Dry/Wet
- 2 Deck A Filter
- 3 Deck A Filter On/Off
- 4 Deck A Absolute/Relative Mode
- 5 FX 2 Dry/Wet
- 6 Deck B Filter
- 7 Deck B Filter On/Off
- 8 Deck B Absolute/Relative Mode

### MIDI Page 3 (Deck A)

- 17 Load Select Deck A  
Shift + Adv.Panel Sel A (Move)
- 18 Load Select Deck B  
Shift + Adv.Panel Sel B (Move)
- 19 Favorite Select Prev  
Shift + Adv.Panel Sel A (Cue)
- 20 Favorite Select Next  
Shift + Adv.Panel Sel B (Cue)
- 21 Track Select  
Shift + Tree Select  
Shift + Tree Expand/Collapse (Push)  
List Mode (Push)
- 22 Snap Mode On/Off



### MIDI Page 3 (Deck A)

- |  |  |   |   |
|--|--|---|---|
| 9 Loop Size Select<br>Loop Active (Push) | 11 Loop Move (Adv.Sel Move)<br>Loop Out (Push) | 13 Hot Cue 1 Set + Store/jump<br>Shift + Hot Cue 1 Delete | 15 Hot Cue 3 Set + Store/jump<br>Shift + Hot Cue 3 Delete |
| 10 Loop Move Size Sel<br>Loop In (Push)  | 12 Track Seek<br>Loop Mode Sel (Push)          | 14 Hot Cue 2 Set + Store/jump<br>Shift + Hot Cue 2 Delete | 16 Hot Cue 4 Set + Store/jump<br>Shift + Hot Cue 4 Delete |





★ Shift Action (Shift + )

- 1 FX 1 Dry/Wet
- 2 Deck A Filter
- 3 Deck A Filter On/Off
- 4 Deck A Absolute/Relative Mode
- 5 FX 2 Dry/Wet
- 6 Deck B Filter
- 7 Deck B Filter On/Off
- 8 Deck B Absolute/Relative Mode

MIDI Page 4 (Deck B)

- 17 Load Select Deck A  
Shift + Adv.Panel Sel A (Move)
- 18 Load Select Deck B  
Shift + Adv.Panel Sel B (Move)
- 19 Favorite Select Prev  
Shift + Adv.Panel Sel A (Cue)
- 20 Favorite Select Next  
Shift + Adv.Panel Sel B (Cue)
- 21 Track Select  
Shift + Tree Select  
Shift + Tree Expand/Collapse (Push)  
List Mode (Push)
- 22 Snap Mode On/Off



### MIDI Page 4 (Deck B)

- |  |  |   |   |
|--|--|---|---|
| 9 Loop Size Select<br>Loop Active (Push) | 11 Loop Move (Adv.Sel Move)<br>Loop Out (Push) | 13 Hot Cue 1 Set + Store/jump<br>Shift + Hot Cue 1 Delete | 15 Hot Cue 3 Set + Store/jump<br>Shift + Hot Cue 3 Delete |
| 10 Loop Move Size Sel<br>Loop In (Push)  | 12 Track Seek<br>Loop Mode Sel (Push)          | 14 Hot Cue 2 Set + Store/jump<br>Shift + Hot Cue 2 Delete | 16 Hot Cue 4 Set + Store/jump<br>Shift + Hot Cue 4 Delete |