

TRAKTOR LE

- 1 TRACK KNOB
- 2 BACK
- 3 PLAY
- 4 PAUSE
- 5 CUE
- 6 JOG WHEEL
- 7 SCRATCH
- 8 FILTER
- 9 SEARCH
- 10 SYNC
- 11 PITCH/KEYLOCK
- 12 PITCH FADER
- 13 PITCH BEND



- 14 LOOP IN
- 15 LOOP OUT
- 16 AUTO LOOP
- 17 LOOP ACTIVE
- 18 FX ON/OFF
- 19 FX SELECT
- 20 FX PARAMETER
- 21 WET/DRY FADER
- 22 DECK TOGGLE