

## PROJECT VIEW

Jump back to Project View



Show next / previous eight Groups



Show next / previous Group



+



Navigate Pattern View by eight Patterns



Navigate Pattern View by one Pattern



+



Show master output, group output, external input or CUE level on level meters




Navigate between Scene Banks



+

1-8


Set loop between two Scenes



+

1-8

Create a loop in between Scenes



+



## BROWSE

Scroll the result list in steps of ten entries



+



Load next / previous preset



+



Set favorites



+



Restore filter created before



+



Reset and jump to the beginning



+



## STEP


Select the amount of Sounds you want to sequence in STEP mode



+

or


or



Navigate through Pattern Pages



Jump to a specific Pattern Page



Jump to a specific Pattern Page Bank



+

1-8

Activate Pattern Follow



+



You can erase events of a specific Sound (PAD MODE) or notes of the same pitch (KEYBOARD) under the playhead




+




+

or



## PAT LENGTH

Press any click-pad on the 8x8 click-pad Matrix to set the length of your Pattern in bars



Or use the Encoder to set the length of your Pattern



## GRID

Choose between common Pattern Grid settings



+



## PIANO ROLL

One octave up or down



One semitone up or down



+



## ARP

Choose an ARP preset by pressing one of the Scene click-pads



+



## VARIATION

Apply VARIATION settings



+



## KEYBOARD

Show next / previous eight Groups



Show next / previous Group



## NOTES

Select a NOTES mode




Add notes on the 8x8 click-pad Matrix to each of your NOTES modes. Edited modes will be saved with the Project / Group

## MACRO / CONTROL

While holding the MACRO or CONTROL click-pad:

► Show Macros or Controls for Sounds on the Smart Strips



► Show Macros or Controls for Groups on the Smart Strips



► Show Macros or Controls for Master on the Smart Strips



The flashing LED indicates the focused Sound, Group or the Master and their respective controls on the Smart Strips

Navigate through plugin slots




Show next or previous parameter page




## LEVEL / AUX / TUNE / SWING

While holding the LEVEL-, AUX-, TUNE-, or SWING-click-pad:


► Show LEVELS, AUX-levels, Tune or Swing for Sound 1-8 on the Smart Strips



► Show LEVELS, AUX-levels, Tune or Swing for Sound 9-16 on the Smart Strips



Hold SHIFT + LEVEL to show the panning for either the Groups or the Sounds on the Smart Strips



Hold SHIFT + AUX to show AUX 2 for either the Groups or the Sounds on the Smart Strips




Show next or previous eight Sounds



## LOCK

Create different LOCK states saved on the 8x8 click-pad Matrix.




Enable morphing between the different LOCK states in the on-screen-overlay. You can also edit each state when selecting the corresponding click-pad

## GLOBAL FUNCTIONS

Hold SHIFT to fine edit parameter values (This Also applies to some on-screen-overlay parameters)



Clear modulation from a specific parameter



When holding MACRO, LEVEL, AUX, CONTROL, TUNE or SWING, double tap on a Smart Strip to reset the parameter to default



Switch between momentary and toggle behavior (e.g. MUTE, SOLO)

